


FITTING INSTRUCTION

Clamp mark in acc. with		Cables joining
ISO	PN	
1	L	Left directional lights
2	+	Rear fog lights
3	31	Ground
4	R	Right directional lights
5	58R	Right side parking lights
6	54	Stoplights
7	58L	Left side parking lights



This towbar is designed to assembly in following cars: **PEUGEOT 406 D8, D9 ESTATE**, produced since 1996 till 02.1999 and since 03.1999 till 2004, catalogue no. **F08A** and is prepared to tow trailers max total weight **1700 kg** and max vertical load **80 kg**.

From manufacturer

Thank you for buying our product. Their reliability has been confirmed in many tests. Reliability of towbar depends also on correct assembly and right operation. For this reasons we kindly ask to read carefully this instruction and apply to hints.

The towbar should be install in points described by a car producer.

The instruction of the assembly

1. Find holes in the chassis on the left and right side then put the special caged nuts M10 (pos. 14) from the towbar accessories
2. Fix the side supports (pos. 4 and 5) through holes (pos. A) with bolts M10x35mm (pos. 8).
3. Position the bar of towbar (pos. 1) between the supports and then fix with M12x35mm bolts (pos. 7) through holes (pos. B and C).
4. Fix the socket plate (pos. 3) as shown on the drawing.
5. Tighten all nuts and bolts according to the torque shown in the table.
6. Fix body of the automat (pos. 20) using bolts M12x25mm (pos. 6) from accessories. Place tow-ball (pos. 2) according to supplied instruction.
7. Connect electric wires of 7-poles socket according to the instruction of the car. (Recommend to make at authorized service station).
8. Complete the paint cover of towbar (during the mounting paint cover could be destroyed).

Torque settings for nuts and bolts (8,8):

M 8	25 Nm	M 10	55 Nm
M 12	85 Nm	M 14	135Nm

NOTE

After install the towbar you should get adequate note in registration book (at authorised service station).The car should be equipped with:

- Indicators
- Tow mirrors

After 1000km of exploitation check all bolts and nuts. The ball of towbar must be always kept clear and conserve with a grease.

Towbar accessories:

Pos. 1	Name: Main bar Quantity: 1	Pos. 5	Name: Left bracket Quantity: 1	Pos. 10	Name: Plain washer Quantity: 10 Dim.: \varnothing 13 mm	Pos. 16	Name: Plain washer Quantity: 2 Dim.: \varnothing 8,5 mm
Pos. 2	Name: Tow ball Quantity: 1	Pos. 6	Name: Bolt 8,8 B Quantity: 4 Dim.: M12x25mm	Pos. 11	Name: Plain washer Quantity: 4 Dim.: \varnothing 10,5 mm	Pos. 17	Name: Nut 8 B Quantity: 1 Dim.: M8
Pos. 3	Name: Socket plate Quantity: 1	Pos. 7	Name: Bolt 8,8 B Quantity: 6 Dim.: M12x35mm	Pos. 12	Name: Spring washer Quantity: 10 Dim.: \varnothing 12,2 mm	Pos. 18	Name: Spring Quantity: 1
Pos. 4	Name: Right bracket Quantity: 1	Pos. 8	Name: Bolt 8,8 B Quantity: 4 Dim.: M10x35mm	Pos. 13	Name: Spring washer Quantity: 4 Dim.: \varnothing 10,2 mm	Pos. 19	Name: Ball cover Quantity: 1
		Pos. 9	Name: Nut 8 B Quantity: 2 Dim.: M12	Pos. 14	Name: Caget nut Quantity: 4 Dim.: M10	Pos. 20	Name: Body of the automat Quantity: 1
		Pos. 15	Name: Bolt 8,8 B Quantity: 1 Dim.: M8x30mm	Pos. 21	Name: Body plug Quantity: 1		



PPUH AUTO-HAK S.J.

Produkcja Zaczepów Kulowych
Henryk & Zbigniew Nejman
76-200 SŁUPSK ul. Słoneczna 16K
tel/fax (059) 8-414-414; 8-414-413
E-mail: office@autohak.com.pl
www.autohak.com.pl

Towing hitch (without electrical set)

Class: **A50-X** Cat. no. **F08A**

Designed for:

Manufacturer: **PEUGEOT**

Model: **406**

Type: **D8, D9 ESTATE**

produced since 1996 till 02.1999

and since 03.1999 till 2004

Technical data:

D-value: 9,3 kN

maximum trailer weight: **1700 kg**

maximum vertical cup load: **80 kg**

Approval number according to Directive 94/20/EC: **e20*94/20*1091*00**

Foreword

This towbar is designed according to rules of safety traffic regulations. The towing hitch is a safety component and can be install only by qualified personnel. Any alteration or conversion of the towing hitch is prohibited and would lead to cancellation of design certification. Remove insulating compound and underseal from vehicle (if present) in the area of the matting surfaces of the towing hitch.

The vehicle manufacturer's specifications regarding trailer load and max. vertical cup load are decisive for driving whereat values for the towing hitch cannot be exceeded.

D-value formula:

$$\frac{\text{Max trailer weight [kg]} \times \text{Max vehicle weight [kg]}}{\text{Max trailer weight [kg]} + \text{Max vehicle weight [kg]}} \times \frac{9,81}{1000} = D \text{ [kN]}$$