


## FITTING INSTRUCTION

Clamp mark in acc. with		Cables joining
ISO	PN	
1	L	Left directional lights
2	+	Rear fog lights
3	31	Ground
4	R	Right directional lights
5	58R	Right side parking lights
6	54	Stoplights
7	58L	Left side parking lights



This towbar is designed to assembly in following car:  
**SUZUKI LIANA** produced since 2001 till 2008, catalogue number **W18**  
 and is prepared to tow trailers max total weight **1200 kg** and max vertical load **60 kg**.

### *From manufacturer*

Thank you for buying our product. Their reliability has been confirmed in many tests. Reliability of towbar depends also on correct assembly and right operation. For this reasons we kindly ask to read carefully this instruction and apply to hints.

*The towbar should be install in points described by a car producer.*

## The instruction of the assembly

1. Disassemble the bumper and brackets.
2. Get out the spare wheel.
3. From the boot take out the carpet and cover panels (side and rear).
4. To rear part of the car put bar of the towbar (pos. 1) – holes pos. A agree with original holes
  - mark points through holes B and C ( put away the bar)
  - in marked holes drill holes using bit  $\varnothing 10,5$  mm
5. Put the bar again and
  - through all holes put bolts M10x50mm (pos. 12) and fix with elements 4 and 5 (elements 4 and 5 put from inside)

**Attention!!!** Before fix, put distance sleeves! (see drawing)
6. Through holes pos. D in elements 4 and 5 drill holes using bit  $\varnothing 10,5$ mm and next fix with elements 6 and 7 (elements 6 and 7 put underneath the car) see drawing.
7. Reassemble the bumper after cut out (in axis) his fragment length 85 mm, width 55 mm.
8. Fix tow-ball (pos. 2) and socket plate (pos. 3) using bolts M12x75mm (pos. 11) from accessories.
9. Tighten all bolts according to the torque shown in the table.
10. Mount side panels (cut out fragments for bolt heads).
11. Connect electric wires according to the instruction of the car. (Recommend to make at authorized service station)
12. Supplement the paint coating damaged during assembly.

Torque settings for nuts and bolts (8,8):

<b>M 8</b>	25 Nm	<b>M 10</b>	55 Nm
<b>M 12</b>	85 Nm	<b>M 14</b>	135 Nm





### NOTE

After install the towbar you should get adequate registration in registration book (at authorised service station).The car should be equipment with:

- Indicators
- Tow mirrors

After 1000km of exploitation check all bolts and nuts. The ball of towbar must be always kept clear and conserve with a grease.

## Towbar accessories:

Pos. 1 Name: Main bar Quantity: 1	Pos. 6 Name: Left fish-plate Quantity: 1	Pos. 12 Name: Bolt 8,8 B Quantity: 6 Dim.: M10x50mm	Pos. 18 Name: Plain washer Quantity: 12 Dim.: $\varnothing$ 10,5 mm
			
	Pos. 7 Name: Right fish-plate Quantity: 1	Pos. 13 Name: Bolt 8,8 B Quantity: 6 Dim.: M10x35mm	Pos. 19 Name: Spring washer Quantity: 2 Dim.: $\varnothing$ 12,2 mm
			
Pos. 2 Name: Tow ball Quantity: 1	Pos. 8 Name: Distance sleeve Quantity: 2 Dim.: $\varnothing$ 17,2x2.35mm L=16mm	Pos. 14 Name: Nut 8 B Quantity: 2 Dim.: M12	Pos. 20 Name: Spring washer Quantity: 4 Dim.: $\varnothing$ 10,2 mm
			
Pos. 3 Name: Socket plate Quantity: 1	Pos. 9 Name: Distance sleeve Quantity: 2 Dim.: $\varnothing$ 17,2x2.35mm L=12mm	Pos. 15 Name: Nut 8 B Quantity: 12 Dim.: M10	Pos. 21 Name: Ball cover Quantity: 1
			
Pos. 4 Name: Left bracket Quantity: 1	Pos. 10 Name: Distance sleeve Quantity: 2 Dim.: $\varnothing$ 17,2x2.35mm L=10mm	Pos. 16 Name: Washer Quantity: 6 Dim.: $\varnothing$ 35x $\varnothing$ 12x4mm	
			
Pos. 5 Name: Right bracket Quantity: 1	Pos. 11 Name: Bolt 8,8 B Quantity: 2 Dim.: M12x75mm	Pos. 17 Name: Plain washer Quantity: 2 Dim.: $\varnothing$ 13 mm	
			



## PPUH AUTO-HAK S.J.

Produkcja Zaczepów Kulowych  
Henryk & Zbigniew Nejman  
76-200 SŁUPSK ul. Słoneczna 16K  
tel/fax (059) 8-414-414; 8-414-413  
E-mail: office@autohak.com.pl  
www. autohak.com.pl

### Towing hitch (without electrical set)

Class: **A50-X** Cat. no. **W18**

Designed for:

Manufacturer: **SUZUKI**

Model: **LIANA**

produced since 2001 till 2007

Technical data:

**D-value: 6,9 kN**

maximum trailer weight: **1200 kg**

maximum vertical cup load: **60 kg**

Approval number acc. to regulations EKG/ONZ 55.01: **E20-55R-01 1397**

### Foreword

This towbar is design according to rules of safety traffic regulations. The towing hitch is a safety component and must be installed only by qualified personnel. Any alteration or conversion to the towing hitch is prohibited and would lead to cancellation of design certification. Remove insulating compound and underseal from vehicle (if present) in the area of the matting surfaces of the towing hitch. The vehicle manufacturer's specifications regarding trailer load and max. vertical cup load are decisive for driving, and values for the towing hitch cannot be exceeded.

*D-value formula:*

$$\frac{\text{Max trailer weight [kg]} \times \text{Max vehicle weight [kg]}}{\text{Max trailer weight [kg]} + \text{Max vehicle weight [kg]}} \times \frac{9,81}{1000} = D \text{ [kN]}$$